

INSTALLATION INSTRUCTIONS
MODEL# 811 & S811
TRIUMPH T100

Item Description	Qty.
8 x 55 mm Socket Head Bolts	4
5/16" x 1"-3/16" Aluminum Spacers	4
Mounting Bracket	2
Tube of Silicone Lubricant	1

- 1.) Remove seat. Remove top bolt on shock. Remove the two bolts holding the grab rail on. Install mounting bracket on using the factory bolt in the shock and the 8 x 55 mm socket head bolts and 5/16" x 1"- 3/16" aluminum spacers as shown in figure 1.

- 2.) Repeat Procedure on opposite side.

- 3.) Tighten all bolts; do not over tighten, apply a small amount of silicone lubricant to rubber grommets to aid in mounting bags. Mount bags over spools and secure with clips retained inside of bags.

SADDLEBAG CARE INSTRUCTIONS

Do not exceed 20 lbs. per saddlebag this includes sitting or standing on bags, it is a common occurrence for a non-rider to attempt to sit on bags, this also may void warranty.

Periodically, apply a small amount of silicone lubrication to rubber mounting points. Saddlebags will be easier to mount and remove.

Remove grease, oil or mud with mild detergent and water. For fast touch-up, *Windex* or *Turtle Wax F-21* will restore original luster. The use of any other chemicals may discolor the saddlebags.

Whenever possible, release locks on saddlebag lids to allow the gaskets to expand during storage.

If you use bags to ice down drinks, later remove bags, drain water and blot up excess water. The foam interior lining is closed-cell foam and does not retain water. Leave lids open until interiors are dry.

Use white *Scotch Brite* scour pad (ultra-fine, only) to remove scratches & shiny spots and restore luster. This can be purchased at an automotive supply store.

When locking or unlocking saddlebags, place one hand on top of bag near lock and apply a moderate amount of pressure while turning the key. This compresses the weather-seal enabling the locking mechanism to turn freely.

Always inspect to verify each of the saddlebag mounting clips on inside of bag is properly installed when mounting bags. Clips fit into groove on mounting spool. Failure to perform this correctly can cause severe damage and may void warranty.

Installation Instructions

Triumph T100

Model# 811 & S811

Figure 1

